

IVECO Eurocargo E6 Allison Transmission




Eurocargo E6

DID YOU KNOW THAT

The gear displayed in the instrument cluster when the exhaust brake is **OFF** will be the number “5” as this is the number of gears available. The actual gear is not displayed.



The gear displayed in the instrument cluster when the exhaust brake is **ON** will be the number “2” as this is the gear that the Allison is trying to achieve. The actual gear is not displayed.



Specifications

Maximum input Torque	Nm	1261
Spread		4,65
Lenght	mm	846
Weight	kg	260 / 300*
Oil capacity	Lt	25 / 27*
Input speed	rpm	2000÷2800

* With Hydraulic Retarder (CCP 237)

Ratios

1	3,49 : 1
2	1,86 : 1
3	1,41 : 1
4	1,00 : 1
5	0,75 : 1
Rev	5,03 : 1

Torque Coverter

HP Range	Model	Stall Torque Ratio
220 ÷ 250	TC415	2,35
280 ÷ 320	TC418	1,98



S3000

